


# CENTRONIK USERS MANUAL ON/OFF DUTY





## INDEX

|   | Page |
|---|------|
| 1- Centronik electric actuators description ..... | 2    |
| 2- Electric connection .....                      | 3    |
| 3- Setting procedure .....                        | 5    |
| 4- Remote inputs .....                            | 7    |
| 5- Operation ON/OFF Duty .....                    | 7    |
| 6- Notes .....                                    | 8    |


### CAUTION



Electric actuators are high value devices. In order to prevent damage in their handling, setting and use, it is essential to follow all the points in this manual.

The actuator is an electrical device, therefore you should take into account the EN 60204, Directive 73/23/EEC safety standards.

The centork electric actuators must be handled with care and caution.



## 1. CENTRONIK ELECTRIC ACTUATORS DESCRIPTION.

The CENTRONIK is an electronic module able to control any CENTORK electric actuator's operation. The unit consists of several PCBs containing a microprocessor, so the unit should be handled very carefully. The CENTRONIK has two main operating modes selectable by the front panel selector: LOCAL and REMOTE.

In the OFF position, the actuator remains connected but does not work.

In the LOCAL mode, the CENTRONIK only follows the front panel push buttons operation. In the REMOTE mode, the operation is made via the remote inputs.

The CENTRONIK unit is part of a complete CENTORK ELECTRIC ACTUATOR. All the points stated in the «Electric actuators installation and maintenance manual» should be followed.

Both «CENTRONIK users manual» and «Electric actuators installation and maintenance manual» are supplied together.





Fig. 1


In the front panel (fig 1), the user will find the following described items:

### Open pushbutton




Is represented by this symbol. This is the pushbutton used to make the actuator run in the Open direction in LOCAL mode.

### Stop pushbutton



Is represented by this symbol. This is the pushbutton used to stop any Open/Close operation in LOCAL mode.

### Close pushbutton



Is represented by this symbol. This is the pushbutton used to make the actuator run in the Close direction in LOCAL mode

### DES pushbutton



Is represented by this symbol. This is the pushbutton we will have to use to enable the actuator movement, after a torque dependant stop, in the same direction it stopped . Note that the actuator will stop as soon as the CENTRONIK detects shaft movement.

### LED L1

Red: The actuator has arrived to the OPEN position.  
 Red blinking: The actuator is running in the OPEN direction.  
 Yellow blinking: Failure, both FRC1 and FRA1 are switched.

### LED L2

Yellow: Blinker failure stop.  
 Red: Overtemperature stop (TRM).  
 Red blinking: Overtemperature happened and has dissapeared.

### LED L3

Green: The actuator has arrived to the CLOSE position.  
 Green blinking: The actuator is running in the CLOSE direction.  
 Yellow blinking: Failure, both FRC1 and FRA1 are switched.

### LED L4

Red: Torque dependant stop in OPEN direction.  
 Green: Torque dependant stop in CLOSE direction.  
 Yellow blinking: Failure, both FPC1 and FPA1 are switched.

### LED L5

Green: Correct phase connection.  
 Red: Phase missing.

## 2. ELECTRIC CONNECTION

### CAUTION



When handling electric equipment, take into account the safety standards (EN 60204, Direc. 73/23/EEC).

Check that the type of current, voltage and frequency suits the actuator according to motor nameplate.

When dismantling the electric connection cover, we find, inside this cover, the electric connection diagram for each actuator.

The IP67 degree of protection, IP68 (on request), is only guaranteed if the correct cable glands are used.

**CAUTION**

**Do not attempt to lever off the cover with a screw driver as this will damage the «O» ring seal. The wiring scheme fixed in the cover is particular to each actuator and must not be interchanged with any other actuator.**

**Types of connection:****1- Plug-socket connectors with screws :**


- a) Unscrew the attachment plate from the connection cover.
- b) Feed the cable(s) through the cable glands<sup>1</sup>.
- c) With a suitable screwdriver, connect the cables for the control signals according to the electric connection diagram.
- d) Connect the 3 phases L1, L2, L3 to the connections 1, 2 and 3 (for clockwise rotation). Connect the earth cable to the earth connection of the plug.
- e) Once you have checked that the connections have been carried out properly, screw the attachment plate back to the connection cover respecting the direction of the connectors.
- f) Close the connection cover and check the proper connection, the state of the o-ring seal and the proper installation of the latter, greasing it slightly. Fasten the 4 screws crosswise.
- g) Tighten cable glands to ensure enclosure IP67 (IP68 on request).

**2- Terminals connection :**

- a) Feed the cable(s) through the cable glands<sup>1</sup>.
- b) With a suitable screwdriver, connect the cables for the control signals according to the electric connection diagram.
- c) Connect the 3 phases L1, L2, L3 to the connections U1, V1 and W1 (for clockwise rotation). Connect the earth cable to the earth connection.
- d) Once you have checked that the connections have been properly carried out, close the connection cover and check the proper connection, the state of the o-ring seal and the proper installation of the latter, greasing it slightly. Fasten the 4 screws crosswise.
- e) Tighten cable glands to ensure enclosure IP67 (IP68 on request).

**3- Plug-socket connectors with crimp :**

- a) Unscrew the attachment plate from the connection cover.
- b) Feed the cable(s) through the cable glands<sup>1</sup>.
- c) With a suitable crimping tool, connect the cables to the control signals according to the electric connection diagram.
- d) Connect the 3 phases L1, L2, L3 to the connections 1, 2 and 3 (for clockwise rotation). Connect the earth cable to the earth connection of the plug.
- e) Once you have checked that the connections are properly done, screw the attachment plate back to the connection cover respecting the direction of the connectors.
- f) Close the connection cover and check the proper connection, the state of the o-ring seal and the proper installation of the latter, greasing it slightly. Tighten the 4 screws crosswise.
- g) Tighten cable glands to ensure enclosure IP67 (IP68 on request).



<sup>1</sup> The cable glands are not supplied with the Standard version.

**CAUTION**



CENTORK actuators are provided with thermostiches mounted in the windings of the motor. The protection of the motor is only achieved with a proper connection for these thermostats. Centork guarantee for the motor is not valid if this connection is not properly done.

In the case of 1NA+1NC double microswitches, only the same potential can be connected through both circuits. For different potentials, two double microswitches must be used.

**3. SETTING PROCEDURE**

The standard configuration of a CENTRONIK programmable electronic control unit is :

- 1- Operation mode 1
- 2- Direction to close OFF (Clockwise)
- 3- Digital outputs / relays configuration N.5 (Mode 4)
- 4- Remote Mode selection ON (Remote Parallel)


Only if needed, the programation of the CENTRONIK is made as follows:

**CAUTION**



This is a sensible electronic device. Manipulation of setting switches should be made very carefully, in a way that other electronic components are not damaged.

- 1- With the selector in the OFF position, take off the front cover of the unit.
- 2- In the PCB, the setting switches are located as indicated in the next figure



3- The meaning of the switches and the different combinations are described in the following tables:

| SW1 | SW2 | SW3 | Operation modes |
|-----|-----|-----|-----------------|
| OFF | OFF | OFF | free            |
| ON  | OFF | OFF | Mode 1          |
| OFF | ON  | OFF | Mode 2          |
| ON  | ON  | OFF | Mode 3          |
| ON  | ON  | ON  | Test Mode       |

| SW4 | Direction to close |
|-----|--------------------|
| OFF | Clockwise          |
| ON  | Anti-clockwise     |

| SW5 | SW6 | SW7 | Config. Dig out./relays |
|-----|-----|-----|-------------------------|
| OFF | OFF | OFF | N° 1 - Mode0            |
| ON  | OFF | OFF | N° 2 - Mode1            |
| OFF | ON  | OFF | N° 3 - Mode2            |
| ON  | ON  | OFF | N° 4 - Mode3            |
| OFF | OFF | ON  | N° 5 - Mode4            |
| ON  | OFF | ON  | free - Mode5            |
| OFF | ON  | ON  | free - Mode6            |
| ON  | ON  | ON  | Test Mode               |

| SW8 | Remote Mode Selection |
|-----|-----------------------|
| OFF | Remote Serial         |
| ON  | Remote Paralel        |

Factory default

Description of the operation modes:

- Mode1 :

This is the Open by limit switching and Close by torque switching operation.

- Mode2 :

This is the Open and Close by limit switching operation.

- Mode3 :

This is the Open and Close by torque switching operation.

- Test Mode :

This is not an operation mode. It is a test program to control the correct operation of the control hardware.  
Note that some internal connections have to be done before running the program.

**CAUTION**



**THIS TEST PROGRAM SHOULD BE RUN ONLY UNDER THE AUTORISATION OF CENTORK.**

The remote outputs configuration depends on the mode chosen.

As standard, the CENTRONIK is not supplied with output relays.

If the CENTRONIK is equipped with relays, the outputs will be potential free contacts. If it is not, the outputs will give 24 V<sub>DC</sub> with a maximum load capacity of 100 mA.

The remote output modes are described next:

| OUTPUTS  | CONFIGURATIONS |              |              |              |                |
|----------|----------------|--------------|--------------|--------------|----------------|
|          | N° 1           | N° 2         | N° 3         | N° 4         | N° 5           |
| OUTPUT 1 | Valve open     | Torque open  | Valve open   | Valve open   | Valve open     |
| OUTPUT 2 | Valve close    | Torque close | Torque close | Valve close  | Valve close    |
| OUTPUT 3 | LOCAL          | LOCAL        | LOCAL        | Torque open  | Torque op./cl. |
| OUTPUT 4 | REMOTE         | REMOTE       | REMOTE       | Torque close | Motor temp.    |
| OUTPUT 5 | FAILURE        | FAILURE      | FAILURE      | FAILURE      | FAILURE        |



Once the connections and programming are made, the switching and signalling unit will have to be adjusted as explained in the «Electric actuators installation and maintenance manual».

**CAUTION**



**Note that in the operation modes 1 and 3, the FRC limit switches will have to be set to operate shortly before reaching the end CLOSED position. If not, the incorrect indications of the CENTRONIK unit could cause malfunction in the process.**

#### 4. REMOTE INPUTS

To operate the CENTRONIK remotely, the remote input should be connected to the common input following the corresponding wiring diagram (see technical sheets).

#### 5. OPERATION ON/OFF DUTY

For LOCAL operation, set the front panel selector on the LOCAL position and use the front panel buttons to OPEN, CLOSE and STOP the actuator.

For REMOTE operation, set the front panel selector on the REMOTE position and after wiring remote switches as indicated, use remote switches to operate the actuator.

The CENTRONIK can also be operated by a serial line. These are the communication's characteristics:

- Transmission speed: 9600 BPS.
- Character format: 1 start bit, 8 data bits, parity even y 1 stop bit.

The communication protocol used is an adapted ADPL-10 version.

For more information about the characteristic of the protocol used such as message format, message sequency and data format refer to the 'Centronik operation. Serial line' brochure.

The CENTRONIK software, has a «movement detection» function. If during the next 6 seconds after the last order no shaft movement is detected the unit will stop the operation. After correcting the problem, the Stop pushbutton should be pressed to reset the unit.

The unit also incorporates a phase missing and an inverse phase connection detection system. Both of them are indicated in the front panel.

Every CENTRONIK is provided with two main fuses. If needed, they should be changed as follows:

- 1- Unscrew the electrical connection cover.
- 2- Unscrew the correspondant fuseholder and change the fuse. Standrad 20 x 5 mm 500 mA normal blow fuses are used.
- 3- Screw both fuseholder and electrical connection back. Check the proper connection, the state of the o-ring seal and the proper instalation of the latter, grasing it slightly. Fasten the 4 screws crosswise.
- 4- Tighten cable glands to ensure enclosure IP67 (IP68 on request).


**CAUTION**



**Make sure a proper ground (GND) connection of the unit is done.**

Notes :





**CENTRALAIR, S.A.**

Portu Etxe, 23,25 - **E 20009 SAN SEBASTIAN** - Apdo. 735 - 20080 San Sebastián - Tfno.: 34 943 31 60 31- Fax : 34 943 21 76 75  
Avda. Zumalacarregui, 50 - **E 48006 BILBAO** - Apdo. 1283 - 48080 Bilbao - Tfno.: 34 94 412 39 00 - Fax : 34 94 412 66 29  
Provenza, 551- **E 08026 BARCELONA** Tfno.: 34 93 348 08 11 - Fax : 34 93 456 00 20  
Yaserías, 41- **E 28005 MADRID** Tfno.: 34 91 474 62 22 - Fax : 34 91 474 12 93

E-mail [sales@centralair.es](mailto:sales@centralair.es)  
<http://www.centork.com>

**AUTOMAIR NORTE LDA.**

Rua Marqués de Soveral, 2-A - **P1700 LISBOA** - Tfno.: 351 (01) 848 93 96 - Fax : 351 (01) 848 92 02  
Rua Luis de Campos, 42 - **P4520 FEIRA** - Tfno.: 351 (056) 37 31 10 - Fax : 351 (056) 37 31 11

---